



Unsprung Handle Version

Some of our lever handles come as 'unsprung', which means there is no spring incorporated into the handle. The only thing helping the lever to return to its original position is the strong spring inside the latch itself.

Split Spindle

A standard split spindle which passes through the latch and into the slot on the back of the lever handle. For use on doors with a maximum thickness of 44mm (larger doors can be accommodated with a longer spindle - see the accessories category on our website).

'Heavy Duty' Tubular Mortice Latch

Designed to be used with any of our 'unsprung' lever handles as it has a strong strength spring in the case. To be mortised into the door and screw fixed in place.

Receiver Plate

Screw fixed to the frame of the door to allow the latch to be received.

Wood Screw Fixings

The majority of our lever handles actually come supplied with wood screws for surface fixing to your door, whereas some have the necessary bolt-through fixings supplied.

Tubular Mortice Latch - Heavy Duty

A heavy duty tubular mortice latch for use with any of our 'Unsprung' lever latch handles or door knob sets. The heavy duty spring inside the latch helps to return the lever back to its original position once used as there is no internal spring inside the ironmongery.

Product Assembly

Screw or Bolt Fixings





2.5" Latch
Backset: 44mm

This means the centre of your door knob or lever handle will be positioned 44mm away from the edge of your door.



3" Latch
Backset: 56mm

This means the centre of your door knob or lever handle will be positioned 56mm away from the edge of your door.



4" Latch
Backset: 81mm

This means the centre of your door knob or lever handle will be positioned 81mm away from the edge of your door.



5" Latch
Backset: 106mm

This means the centre of your door knob or lever handle will be positioned 106mm away from the edge of your door.

Tubular Mortice Latch - Standard & Heavy Duty

The measurement in the latch name (2.5", 3" etc.) refers to the actual size of the latches case, whereas the critical measurement for positioning of your knob set or lever handle is the 'Backset'. This backset dictates the position of your ironmongery in relation to the edge of your door. When choosing a

latch for use with a knob set we strongly recommend using a 3" latch or bigger to avoid scraping your knuckles on any door architrave or moulding when you turn the knob to open the door. A 3" latch should give you enough clearance to avoid this.